

**MOVE ABSOLUTE**

IMPORT COORDINATES FROM

None

X (MM)	Y (MM)	Z (MM)
100	406	55
X-OFFSET	Y-OFFSET	Z-OFFSET
0	0	0

**MOVE ABSOLUTE**

IMPORT COORDINATES FROM

Tool: Seed Tray (big)

X (MM)	Y (MM)	Z (MM)
0	406	141
X-OFFSET	Y-OFFSET	Z-OFFSET
0	0	-86

**MOVE ABSOLUTE**

IMPORT COORDINATES FROM

Tool: Seed Tray (big)

X (MM)	Y (MM)	Z (MM)
0	406	141
X-OFFSET	Y-OFFSET	Z-OFFSET
0	0	-61

**WRITE PIN**

PIN NUMBER	VALUE	PIN MODE
10	1	Digital

**WAIT**

TIME IN MILLISECONDS

3000

**MOVE ABSOLUTE**

IMPORT COORDINATES FROM

Tool: Seed Tray (big)

X (MM)	Y (MM)	Z (MM)
0	406	141
X-OFFSET	Y-OFFSET	Z-OFFSET
0	0	-86

**MOVE ABSOLUTE**

IMPORT COORDINATES FROM

Plant: Basil (210, 410, 0)

X (MM)	Y (MM)	Z (MM)
210	410	0
X-OFFSET	Y-OFFSET	Z-OFFSET
0	0	180

**WRITE PIN**

PIN NUMBER	VALUE	PIN MODE
10	0	Digital

**MOVE ABSOLUTE**

IMPORT COORDINATES FROM

Tool: Seed Tray (big)

X (MM)	Y (MM)	Z (MM)
0	406	141
X-OFFSET	Y-OFFSET	Z-OFFSET
100	0	-86

**MOVE ABSOLUTE**

IMPORT COORDINATES FROM

Tool: Seed Tray (big)

X (MM)	Y (MM)	Z (MM)
0	406	141
X-OFFSET	Y-OFFSET	Z-OFFSET
0	0	-86